



## Proper Care & Maintenance:

To ensure the product remains in excellent condition, please follow the proper care & maintenance instructions. Failure to adhere to these instructions can void product warranty.

- Do not wash or wax your vehicle for a minimum of 7 days after installation.
- Wash and wax your vehicle as needed.
- Remove any and all bugs, tar, oil, dirt, chemicals, etc from film as soon as possible to prevent staining.
- Do not use solvent based bug and tar remover or cleaners.
- Use soft non-abrasive wash mitts and drying materials.
- If powerwashing, wait at least 30 days after installation and keep the spray tip at least 3 feet away from film.
- Non-abrasive wax or sealant application is recommended once every 4 months.
- The use of polishing compounds, clay bars or waxes that contain dyes or abrasives is prohibited.
- Seek ASWF certified installer to remove film if needed.

---

Installation recommended temperature of the ambient air in the immediate surroundings as well as the substrate surface is between 70°F and 85°F. Installation should be in a contaminate free environment and performed out of direct sunlight.

Shelf life of ASWF PPF is 1 year when stored upright in its original packaging at a temperature of 65°F to 75°F and not exceeding a relative humidity of 50-60%.